
Pressure Switch (NC)
MAIN FUEL PUMP
AUX FUEL PUMP
AUX BATTERY
MAIN BATTERY
SOL
STARTER
ALT
FIREWALL FORWARD
LOWPIN
MAINPUMP
AUXPUMP
MAINFIN
AUXFIN
MAIN FUEL PUMP
AUX FUEL PUMP
LOW FUEL PRESSURE
AUXIO
MAINIO
ALTIO
to EFIS/One
AUXIN
AUXBUS
AUX POWER BUS
AUXON
LOWVOLT
LOW VOLTAGE
CONNCOM
CONNOFF
MAININ
CONNON
MAINBUS
MAIN POWER BUS
MAINON
ALTLITE
ALT FIELD
ALTCOM
ALTOFF
ALTRST
ENGON
ALTIN
SPARE
To Interior Light Switch
D-10A
to D-10 Backup
ECU
ALTFLD
ENGBUS
ENGINE BUS
GND
START
(OPTIONAL)
FUEL PUMPS OFF/ON
PUMP SELECT MAIN/AUTO/AUX
AUX BOOST
AUX BOOST OFF/ON
AUX BUS
AUX BUS OFF/ON
BUS CONNECT OFF/AUTO/ON
MAIN BUS
MAIN BUS OFF/ON
ALTERNATOR OFF/AUTO/RST
ENGINE BUS
ENG BUS OFF/ON
MEM PWR
ECM
MT Prop Controller
PROP CONTROL OFF/ON
Supercharger Controller
SUPERCHARGER OFF/ON
FWL PANEL
GROUND BUS
INST PANEL
GROUND BUS
FWL (BOLT)
2AWG BRAID STRAP
AUXBUS
MAINBUS
D-10A
SL30
FLAP CONTROLLER
FLAPS OFF/ON
PITCH TRIM CONTROLLER
ROLL TRIM CONTROLLER
TRIM OFF/ON
PITOT TUBE
PITOT HEAT OFF/ON
LEFT STROBE
RIGHT STROBE
TAIL STROBE
STROBE LIGHTS OFF/ON
STROBE LIGHTS LOW/HIGH
LEFT WING LIGHT
RIGHT WING LIGHT
TAIL LIGHT
POSITION LIGHTS OFF/ON
SL15
SL40
SL70
ATD-200
EIS
A/P
AUTOPILOT OFF/ON
BMA EFIS/One
EFIS OFF/ON
(REAR VIEW OF SWITCH)
TERMINAL NUMBERING FOR FOR S700-2-10 SWITCH MOUNTED KEYWAY UP
WIGWAG OFF/ON
TAXI LIGHT OFF/ON
LANDING LIGHT OFF/ON
WIGWAG
TAXI LIGHT
LANDING LIGHT
LEFT WING FUEL GAUGE
RIGHT WING FUEL GAUGE
ENGBUS
LEFT STICK INTERFACE
RIGHT STICK INTERFACE
RIGHT STICK OFF/ENABLE
LIGHT DIMMER
DIM
BRIGHT
INTERIOR LIGHT DIMMER
To Power Dist. PCB
INTERIOR LIGHTS OFF/ON
= INSTRUMENT PANEL GROUND BUS
= ENGINE CRANKCASE GROUND
= FIREWALL GROUND BUS